

Gryphon Barcode Scanner Configuration Sheet

NOTE: Use this configuration sheet to properly configure Gryphon scanners with model numbers 4200 & 4220 to function with Destiny. Scan the following barcodes in sequential order (1-5). Ensure that your computer monitor is displaying the desktop and that NO software programs are open.

Default



1. ³ \$ P , A E , P

Enter/Exit Programming




2. \$P

EAN-13 ISBN Conversion = Convert to ISBN



3. \$C3BIS01

Scan Mode - Stand Mode



4. \$CSNRM05

Code 39 Small Quiet Zone on two sides



5. \$CC3LO01

Enter/Exit Programming



6. \$P